3D PRINTING





Allen Wolff

KC7O

9 January 2018

Definitions

- ***Subtractive Manufacturing***
  - ***i.e. machining***
- ***Additive manufacturing***
  - ***A process for making a physical object from a three-dimensional digital model, typically by laying down many successive thin layers of a material***

https://3dprinting.com/what-is-3d-printing/#How-Does-3D-Printing-Work

A Taste of 3D Printing

- ***Limited experience***
  - ***First involvement – June 2016***
- ***Some hints that helped me***
- ***How to get started***
- ***You'll be working and thinking in Metric Units!***



- ***BTW, you will make a lot of scrap***


Get used to it ☺

Basics

- ***Mechanisms***
  - ***Ink Jet printers***
  - ***3D printers***
- ***Software***
  - ***Design***
  - ***Slicing***
- ***Process***
- ***Examples***

Mechanisms

- ***I will concentrate on simple hobby machines***
- ***How they work***

Similarities with Inkjet Printers

http://www.photocopier.org.uk/wp-content/uploads/2011/03/ink-and-ribbon-how-it-works3.png

http://www.bus.umich.edu/KresgePublic/Journals/Gartner/research/90500/90582/90582.html

Tool path
and areas where material is not deposited



Machines & Costs

- ***Based on size and complexity***
  - ***Single or multiple filaments***
  - ***Many choices available***
  - ***Resolution***
  - ***$$$$$***
- ***Professional to Hobby***

Machines & Costs

- **Based on complexity**
  - Single or multiple filaments
  - Many choices available
  - Resolution
  - $$$$$
- **Wanhao Duplicator I3**
  - Monoprice Maker Select 3D v2
  - 8” x 8” x 7” high max part size
  - ~ $300 *(7/17)*
  - Easy to upgrade & improve
  - ~250 Watts using µSD card

WANHAO USA

Filament Holder

Controller & Power Supply




WANHAO USA
Extruder & Fans
Heated Build Plate

WANHAO USA

Process



Process

Part Design

Format as .STL

Slicing Program



Process



Process

Part Design

Format as .STL

Slicing Program

Machine .gcode

Machine interface

Machine

Micro SD card or USB cable

Design Software

- **Part design**
  - **Autocad** **$$$$$**
  - **Solid Works** **$$$$$**
  - **SketchUp** **Free**
  - **3dslash** **Free**
  - **123D Design** **Free**
  - **DesignSpark** **Free**
    - **Mechanical**
  - **FreeCAD** **Free**
  - **OpenSCAD** **Free**

Export Formats

- **3D solid formats:**
  - **DWG, DXF, 123DX, SAT, STEP**
- **3D mesh formats:**
  - **STL, VRML, X3D**
- **STL - STereoLithography**
  - **Files are the most common**
  - **This format only describes the surface geometry of the object, and can't store properties like color or texture**
  - **This is generally ok when printing in one color**

Programs

OpenSCAD
design

→ ***xxx.scad*** →

xxx.stl

Or From the Internet

Cura
slicing

→ ***x.gcode***

Pronterface
machine interface

USB

Programs

OpenSCAD
design

→ ***xxx.scad*** →

xxx.stl

Or From the Internet

Cura
slicing

→ ***x.gcode***

Micro SD card

Recommended

gcode

- ***The line by line code that defines the printers tool path & operation***
- ***Created by slicing program (i.e. Cura)***
- ***Not necessary to know!***
- ***Just for information***
- ***Goes on for ten's of thousands of lines***

```
M190 S70.000000          Temps
M109 S210.000000
;Sliced at: Thu 23-06-2016 16:06:04
;Basic settings: Layer height: 0.1 Walls: 0.8 Fill: 20
;Print time: 3 hours 25 minutes
;Filament used: 2.38m 18.0g
;Filament cost: None
;M190 S70 ;Uncomment to add your own bed temperature line
;M109 S210 ;Uncomment to add your own temperature line
G21        ;metric values
G90        ;absolute positioning
M82        ;set extruder to absolute mode
M107       ;start with the fan off      Fan off
G28 X0 Y0  ;move X/Y to min endstops     Move to stops
G28 Z0     ;move Z to min endstops
G1 Z15.0 F9000 ;move the platform down 15mm
G92 E0                  ;zero the extruded length
G1 F200 E3              ;extrude 3mm of feed stock
G92 E0                  ;zero the extruded length again
G1 F9000
;Put printing message on LCD screen
M117 Printing...  Print starts

;Layer count: 98
;LAYER:0
M107
G0 F9000 X69.709 Y4.512 Z0.300
;TYPE:SKIRT
G1 F1200 X96.889 Y4.512 E0.51127
G1 X99.362 Y9.927 E0.62325
G1 X115.276 Y44.814 E1.34455
G1 X115.276 Y60.112 E1.63231
G1 X69.537 Y60.112 E2.49269
G1 X69.537 Y36.930 E2.92875
G1 X84.467 Y36.930 E3.20959
G1 X69.709 Y4.512 E3.87961
G0 F9000 X70.330 Y4.912
```

Machine Components

(Wanhao Duplicator I3)

- *0.4 mm nozzle*
  - *0.01575” ~ 5 times a hair diameter*
- *Hot end with nozzle*



Heater & Thermocouple



Machine Components

(Wanhao Duplicator I3)

- **Hot Bed**



Materials

- *Usually 1 Kg spools*
  - *~$25 - $30*
  - *I use Hatchbox – 1.75 mm*
  - *~ 330 meters or 1080 feet*
- *Available in multiple colors and materials*


HATCHBOX
3D PRINTER FILAMENT
PLA

Materials

- Come in 1 Kg spools
  - ~$25 - $30
  - I use Hatchbox – 1.75 mm
  - ~ 330 meters or 1080 feet
- Comes in multiple colors
- Types
  - PLA
  - ABS
  - Wood
  - Nylon
- Quality of the filament is critical

Common Materials

- ***PLA - Polylactic acid***
  - ***Easy to Print***
  - ***Biodegradable & Nontoxic***
  - ***Porous (clear coat to water proof)***
  - ***Should be kept dry (as with all filaments)***
    - ***I use Home Depot Buckets & covers with desiccant***
    - ***The filaments come with desiccant packs***

http://www.wikiwand.com/en/Polylactic_acid

Common Materials

- **ABS - Acrylonitrile Butadiene Styrene**
  - Durable, Impact Resistant
  - Warpage
  - Smells
  - Inhalation issues
    - Heating may release vapors which may be irritating

- **Wood**
  - Wood fibers in PLA
- **Nylon**
  - Strong, Flexible, Durable
  - Harder to work with

PLA - Polylactic acid	Easy to Print, Biodegradable
ABS - Acrylonitrile Butadiene Styrene	Durable, Impact Resistant
PETG (XT, N-Vent)	Flexible, Durable
nGen	Like PETG, but Easier to Print, Heat Resistant, Transparent
Flexible, TPE, TPU	Extremely Flexible, Rubber-Like
TPC	Extremely Flexible, Rubber-Like, Chemical-/ Heat-/ UV Resistant
HIPS	Disolvable, Biodegradable
PVA	Disolvable, Water Soluble, Biodegradable, Oil Resistant
Wood PLA	Wood Finish
Nylon	Strong, Flexible, Durable
PET (CEP)	Strong, Flexible, Durable, Recyclable
Carbon Fiber PLA	Rigid, Stronger Than Pure PLA
Metal PLA	Metal Finish
PC Polycarbonate	Strongest, Flexible, Durable, Transparent, Heat Resistant
Conductive PLA	Conductive
ASA	Rigid, Durable, Weather Resistant
PP	Flexible, Chemical Resistance
PETT (T-Glase)	Strong, Flexible, Transparent, Clear
POM, Acetal	Strong, Rigid, Low Friction, Resilient
Glow-In-The-Dark PLA	Luminous, Flourescent
Wax (MOLDLAY)	Melts Away
PMMA, Acrylic	Rigid, Durable, Transparent, Clear, Impact Resistant
PC/ABS	Rigid, Durable, Impact Resistant, Resilient, Deflecting Heat
Cleaning	Cleaning
Magnetic Iron PLA	Magnetic
Sandstone (LAYBRICK)	Sandstone Finish
Color Changing PLA	Changes Color

Temperatures Based on Materials

- PLA (recommended initially)
  - Hot End – Extrusion/Nozzle
    - 210°C (180°C - 210°C) => (356°F - 410°F)
  - Hot Bed
    - Not heated or 70°C
    - Experimentation
- ABS
  - Hot End – Extrusion/Nozzle
    - 230°C (210°C - 240°C) => (410°F - 464°F)
  - Hot Bed
    - 70°C (55°C - 85°C) => (131°F - 185°F)
    - Experimentation

YOUR CREATIVITY, OUR TOOLS.

Bed Adhesion

None – no additional material

Brim

Raft

Determine by experimentation

Bed Adhesion

Sometimes too much!

ABS

Bed Adhesion

Sometimes breaks loose!

PLA





Printer Adjustments

- ***Printer bed must be level***
- ***Extruder should be one to two paper thickness away from bed across the build area – depending on the bed***
- ***Prints always start from "Home"***
  - ***X=0, Y=0, Z=0***
  - ***Front left***
- ***Bed temperatures critical for each material & type of bed material***

Part Adherence to Bed

- **Methods:**
  - Print on Blue painters tape
  - Adhesives to hold part – glue stick
  - Acqua-Net hair spray
  - Mylar tape
  - Borosilicate Glass Beds
  - print plates

Part Removal

- Scraper 
- Care not to harm the print surface
- Another reason to use a replaceable surface on the bed

Cleaning

- 91% Isopropyl Alcohol and a clean rag
- 70% pads ok too

Problems

- Clogged nozzle
- Models not adhering
- Warping
  - Bed temperature adjustment
  - Head to bed alignment



Shrinkage

Test_Cube_Shrinkage.scad - OpenSCAD

File Edit Design View Help

Editor

```
1  // 1 inch block - shrinkage
2  //KC7O - 20Sept2017
3  $fn=63;
4  difference(){
5  cube([25.4,25.4,5]);
6
7  translate([12.7,12.7,0])
8      cylinder(10,6.35,6.35);
9  }
```

OpenSCAD



Shrinkage


inch/mm
25.33
OFF
ON
ZERO
25.4


inch/mm
25.24
OFF
ON
ZERO
25.4


12.7
inch/mm
12.44
OFF
ON
ZERO

Design

- ***OpenSCAD (free download)***

OpenSCAD

The Programmers Solid 3D CAD Modeller

Donate

Flattr 965

Donate 0

home | about | news | downloads | documentation | gallery | community | github

Recent News

14 Jul 2016

OpenSCAD Customizer



The topic of this year's Google Summer of Code project is...

3 Mar 2016

Google Summer of Code 2016

OpenSCAD, in collaboration with

10 Mar 2015

OpenSCAD is a software for creating solid 3D CAD objects.

It is free software and available for Linux/UNIX, MS Windows and Mac OS X.



Download OpenSCAD

OpenSCAD 2015.03-2 Windows

Other OSs and Versions

Example

- ***Appeared in CQ Magazine***
  - ***October 2016 – PC Board Build Supports***
  - ***"A Brass Set" from QRPme.com***
  - ***Issue – they are brass so you can't power and test your project – potential shorts***


KEY
+12


NT
J2
RCVR
T/R Sw
J1
R
T


ANT
+12V
J2
RCVR
J3
T/R Sw
J1
R
T
KEY
J4
RFP
LOW PASS FILTER
120pf
820pf
1.0uh
1.0uh
QRPme's
TUNA TIN 2
40m XTAL
DVM
Q1
PN2222
OSC
Q2
PN2222
AMP
220pf
1K
56
100pf
HD01 1339

A Better Idea!

Design It & Print It!

The process from idea to part

#8_feet-for presentation.scad* - OpenSCAD

File Edit Design View Help

Editor

```
1
2  $fn=30;
3  rotate([0,90,0])
4 scale([1.2,1.2,1.2]){
5 translate([-12.5,0,2]){
6  //difference(){
7  cube ([10,2,10]);
8  //rotate([90,0,0])
9  //translate([5,5,-7])
10     //cylinder(10,2,2);
11
12 //}
13
14 }
15 }
```

Start with a cube



OpenSCAD

Console

```
Geometries in cache: 5
Geometry cache size in bytes: 7184
CGAL Polyhedrons in cache: 0
CGAL cache size in bytes: 0
Compiling design (CSG Products normalization)...
Normalized CSG tree has 1 elements
Compile and preview finished.
Total rendering time: 0 hours, 0 minutes, 0 seconds
```

Viewport: translate = [37.43 7.93 16.30], rotate = [66.90 0.00 27.80], distance = 140.00

Make a hole

#8_feet-for presentation.scad* - OpenSCAD

File Edit Design View Help

Editor

```
1
2  $fn=30;
3  rotate([0,90,0])
4 scale([1.2,1.2,1.2]){
5 translate([-12.5,0,2]){
6  //difference(){
7  cube ([10,2,10]);
8  //rotate([90,0,0])
9  //translate([5,5,-7])
10     //cylinder(10,2,2);
11
12 //}
13
14 }
15 }
```



Console

```
Geometries in cache: 5
Geometry cache size in bytes: 7184
CGAL Polyhedrons in cache: 0
CGAL cache size in bytes: 0
Compiling design (CSG Products normalization)...
Normalized CSG tree has 1 elements
Compile and preview finished.
Total rendering time: 0 hours, 0 minutes, 0 seconds
```

Viewport: translate = [37.43 7.93 16.30], rotate = [66.90 0.00 27.80], distance = 140.00

#8_feet-for presentation.scad* - OpenSCAD

File Edit Design View Help

Editor

```
1
2  $fn=30;
3  rotate([0,90,0])
4 scale([1.2,1.2,1.2]){
5 translate([-12.5,0,2]){
6  //difference(){
7  cube ([10,2,10]);
8  rotate([90,0,0])
9  //translate([5,5,-7])
10     cylinder(10,2,2);
11
12 //}
13
14 }
15 }
```

Add a cylinder the size of the hole



Console

```
Geometries in cache: 5
Geometry cache size in bytes: 7184
CGAL Polyhedrons in cache: 0
CGAL cache size in bytes: 0
Compiling design (CSG Products normalization)...
Normalized CSG tree has 2 elements
Compile and preview finished.
Total rendering time: 0 hours, 0 minutes, 0 seconds
```

Viewport: translate = [37.43 7.93 16.30], rotate = [66.90 0.00 27.80], distance = 140.00

#8_feet-for presentation.scad* - OpenSCAD

File Edit Design View Help

Editor

```
1
2  $fn=30;
3  rotate([0,90,0])
4 scale([1.2,1.2,1.2]){
5 translate([-12.5,0,2]){
6  //difference(){
7  cube ([10,2,10]);
8  rotate([90,0,0])
9  translate([5,5,-7])
10     cylinder(10,2,2);
11
12 //}
13
14 }
15 }
```

Translate the cylinder to where you want the hole



Console

```
Geometries in cache: 5
Geometry cache size in bytes: 7184
CGAL Polyhedrons in cache: 0
CGAL cache size in bytes: 0
Compiling design (CSG Products normalization)...
Normalized CSG tree has 2 elements
Compile and preview finished.
Total rendering time: 0 hours, 0 minutes, 0 seconds
```

Viewport: translate = [37.43 7.93 16.30], rotate = [66.90 0.00 27.80], distance = 140.00

Use the difference() function

#8_feet-for presentation.scad* - OpenSCAD

File Edit Design View Help

Editor

```
1
2  $fn=30;
3  rotate([0,90,0])
4  scale([1.2,1.2,1.2]){
5  translate([-12.5,0,2]){
6  difference(){
7  cube ([10,2,10]);
8  rotate([90,0,0])
9  translate([5,5,-7])
10     cylinder(10,2,2);
11
12 }
13
14 }
15 }
```



Console

```
Geometries in cache: 5
Geometry cache size in bytes: 7184
CGAL Polyhedrons in cache: 0
CGAL cache size in bytes: 0
Compiling design (CSG Products normalization)...
Normalized CSG tree has 2 elements
Compile and preview finished.
Total rendering time: 0 hours, 0 minutes, 0 seconds
```

Viewport: translate = [37.43 7.93 16.30], rotate = [66.90 0.00 27.80], distance = 140.00

#8_feet.scad - OpenSCAD

File Edit Design View Help

Editor

```
1  //PC Board Feet
2  //Use #8 nylon nut and 3/4" screw
3  //A. Wolff
4  //Original idea from "A Brass
       Set" qrpme.com
5  //70% fill, 0.2 layer
6  //210 & 70 deg C - raft
7  $fn=30;
8  scale([1.2,1.2,1.2]){
9  difference(){
10 cube ([10,2,10]);
11 rotate([90,0,0])
12 translate([5,5,-7])
13 cylinder(10,2,2);
14 }
15 difference(){
16 translate([0,5,0])
17     cube ([10,2,10]);
18 rotate([90,0,0])
19 translate([5,5,-7])
20 cylinder(10,2,2);
21 }
22 translate([8.5,0,-2])
23 cube ([4,12,14]);
24 translate([0,10,-2])
25 cube ([12.5,4,14]);
26 translate([0,0,-2])
27 cube ([10.5,7,2]);
28 translate([0,0,10])
29 cube ([10.5,7,2]);
30 }
```

Once completed and rendered
Export as a .STL file

Console

```
Compiling design (CSG Tree generation)...
Compiling design (CSG Products generation)...
Geometries in cache: 5
Geometry cache size in bytes: 7184
CGAL Polyhedrons in cache: 0
CGAL cache size in bytes: 0
Compiling design (CSG Products normalization)...
Normalized CSG tree has 8 elements
```

Viewport: translate = [9.19 9.21 6.38], rotate = [55.00 0.00 25.00], distance = 74.40

Import the .STL file into CURA



Settings

- ***Layer Height***
  - ***How thick the slices are***
    - ***0.1 mm = "high" resolution***
    - ***0.3 mm = "low" resolution***
    - ***Thicker the layer the shorter the time***
    - ***The smaller the layer the less stepping***
    - ***Strength relationship layer height vs % infill***





K Printing

http://enablingthefuture.org/2014/11/13/tech-talk-thursday-intro-to-3d-printing/



Fine resolution

Half the layer height double the print time

Settings

- ***Number of Shells***
  - ***Solid surface thickness***
    - ***Times the diameter of the nozzle***
    - ***Strength***



http://enablingthefuture.org/2014/11/13/tech-talk-thursday-intro-to-3d-printing/


Cura - 15.04.6
File Tools Machine Expert Help
Basic Advanced Plugins Start/End-GCode
Quality
Layer height (mm) 0.1
Shell thickness (mm) .8
Enable retraction
Fill
Bottom/Top thickness (mm) 0.8
Fill Density (%) 20
Speed and Temperature
Print speed (mm/s) 40
Printing temperature (C) 210
Bed temperature (C) 70
Support
Support type Touching buildplate
Platform adhesion type Brim
Filament
Diameter (mm) 1.75
Flow (%) 100.0
Machine
Nozzle size (mm) 0.4

Two Shells

CURA Settings

- ***Infill Percentage***
  - ***Interior not completely solid***
    - ***Saves time***
    - ***Saves material***
    - ***Sacrifices strength***



http://enablingthefuture.org/2014/11/13/tech-talk-thursday-intro-to-3d-printing/


Cura - 15.04.6
File Tools Machine Expert Help
Basic Advanced Plugins Start/End-GCode
Quality
Layer height (mm) 0.1
Shell thickness (mm) .8
Enable retraction ...
Fill
Bottom/Top thickness (mm) 0.8
Fill Density (%) 20 ...
Speed and Temperature
Print speed (mm/s) 40
Printing temperature (C) 210
Bed temperature (C) 70
Support
Support type Touching buildplate ...
Platform adhesion type Brim ...
Filament
Diameter (mm) 1.75
Flow (%) 100.0
Machine
Nozzle size (mm) 0.4


Cura - 15.04.6
File Tools Machine Expert Help
Basic Advanced Plugins Start/End-GCode
Quality
Layer height (mm) 0.1
Shell thickness (mm) .8
Enable retraction ...
Fill
Bottom/Top thickness (mm) 0.8
Fill Density (%) 20 ...
Speed and Temperature
Print speed (mm/s) 40
Printing temperature (C) 210
Bed temperature (C) 70
Support
Support type Touching buildplate ...
Platform adhesion type Brim ...
Filament
Diameter (mm) 1.75
Flow (%) 100.0
Machine
Nozzle size (mm) 0.4



None
Brim
Raft


Cura - 15.04.6
File Tools Machine Expert Help
Multiply by X
Basic Advanced Plugins Start/End-GCode
Quality
Layer height (mm) 0.2
Shell thickness (mm) .8
Enable retraction
Fill
Bottom/Top thickness (mm) 0.8
Fill Density (%) 70
Speed and Temperature
Print speed (mm/s) 40
Printing temperature (C) 210
Bed temperature (C) 70
Support
Support type Touching buildplate
Platform adhesion type Raft
Filament
Diameter (mm) 1.75
Flow (%) 100.0
Machine
Nozzle size (mm) 0.4
24 minutes
1.39 meter 4 gram
0.10



Save as a .gcode

Load .gcode into Pronterface and connect to printer Can also use a memory card





#8 nylon nut and screw





Can put power to the circuit because it's insulated from the feet

Other Ham Projects

PP_Clip.scad - OpenSCAD

File Edit Design View Help

Editor

```
    pindistx = 12.5;
    pindisty = 15.5;
    pin_dia = 2.5;
    clip_thick =3;
    clip_heigth = 8.5;
    clip_hang = 1;
    clip_width = 3;
    clip_length=41;

module PP_Pin( x, y, z,
    heigth,dia)
{
    detail = 0.2;
        translate([x,y,z])
        {
            cylinder(h=heigth
    ,d=dia,$fs = detail);
        }
}

module clip( x, y, z, heigth,
     side_thick, width,
    clipthick, cliphang)
{
    translate ([-side_thick,
    -width/2,0])
    {
        translate([x,y,z])
        {
            cube ([side_thick
    ,width,heigth]);
        }
        translate([x,y,z+
    heigth])
        {
            cube ([side_thick
    +cliphang,width,clipthick
    /2]);
        }
```



Console

```
Vertices:    698
Halfedges:  2108
Edges:      1054
Halffacets:  720
Facets:      360
Volumes:       2
Rendering finished.
STL export finished.
```

Viewport: translate = [-0.00 -0.00 -0.00], rotate = [55.00 0.00 25.00], distance = 140.00

OpenSCAD 2015.03

PowerPole Clip by metrux

KC7O

Published on November 22, 2012






Tools
Advanced
Settings
Help
Disconnect
Reset
COM3
115200
Motors off
XY: 3000
mm/min Z: 100
Heat: Off
230 (abs)
Set
Bed: Off
60 (pla)
Set
Extrude
Reverse
Length:
Speed:
5.0
mm @
100.0
mm/
min
Print speed:
100
%
Set
Heater: T° 226/230
Bed: T° 109/110
T:226.90 /230 B:109.96 /110 B@:255 @:230
Load File
SD
Restart
Pause
Off
Target
Ex0
Bed
225
200
175
150
125
100
ok 42351
ok 42352
ok 42353
ok 42354
ok 42355
ok 42356
ok 42357
ok 42358
ok 42359
ok 42360
ok 42361
ok 42362
ok 42363
ok 42364
ok 42365
ok 42366
ok 42367
ok 42368
ok 42369
ok 42370
ok 42371
ok 42372
ok 42373
ok 42374
ok 42375
ok 42376
ok 42377
ok 42378
ok 42379
ok 42380
ok 42381
ok 42382
ok 42383
ok 42384
ok 42385
ok 42386
ok 42387
ok 42388
ok 42389
ok 42390
ok 42391
ok 42392
ok 42393
ok 42394
ok 42395
ok 42396
ok 42397
ok 42398
ok 42399
ok 42400
ok 42401
ok 42402
ok 42403







by Sterminato

by Akimitsu

Antenna Element Insulators



File Edit Design View Help

Editor

```
1  //Antenna element grommets
2  //A. Wolff - KC7O
3  //28 January 2017
4  //small element 5mm (0.197")
5  //3/16" = 0.1875
6
7  $fn=60;
8  difference(){
9  union(){
10 cylinder(3,5.5,5.5);
11 cylinder(6,3.9,3.9);
12 }
13 cylinder(10,2.5,2.5);
14 }
```





Insulator for a Loop Antenna





X-Ray View





by WX7JM

Magnet

Other Projects

Bottle Bird Feeder from Thingiverse.com

by Gazorpa




Toys for grandson
from Thingiverse.com

Thingiverse
LeFabShop

Hummingbird Feeder Ant Moat

Commercial 3” x 1 ¾” too small

Designed 4 ½” x 2 ½” & Printed


Problem
Solution

From Thingiverse – a Bottle Opener

by Nelujones

Plug for Umbrella Hole in a Glass Table



Curtain rod hanger for a wall hanging





Impossible 3D Bolt

by CreativeTool


Untitled*
AUTODESK®
123D® DESIGN


XYZ

Fidget From Thingiverse

by timrbsnow

7 hour print





Knob for a #10 Thread












60% fill
.15 mm
USB SD
Printed as one piece

First print failure
15% fill
.3 mm


Triclosan 0.30%
Uses aids in the prevention of: • cavities • plaque
Warnings Keep out of the reach of children under 6 years of age.
brushing is accidentally swallowed, get medical help or contact a Poison
right away. Ask a dentist before use if you have • bleeding or redness
weeks • pain, swelling, pus, loose teeth, or more spacing between teeth
These may be signs of periodontitis, a serious form of gum disease.
Questions or comments?
Call toll-free 1-800-468-6502
www.colgatetotal.com


Fix-All
ADHESIVE • ADHÉSIF
akshay_d21

Benchy

for Benchmark



Calibration and torture-test for 3D printers





The front and rear surfaces of the roof are parallel at a distance of 23.00 mm.



The cylindrical hole and outer top part of the chimney measure 3.00 and 7.00 mm in diameter. The depth of the blind hole measures 11.00 mm.



#3DBenchy's horizontal overall-length from bow to stern measures 60.00 mm.



#3DBenchy's horizontal overall-width from port to starboard measures 31.00 mm.



#3DBenchy's vertical overall-height from top to bottom measures 48.00 mm. The top of the box measures 15.50 mm above the bottom surface.



The box on #3DBenchy's deck measures 12.00 x 10.81 mm on the outside and 8.00 x 7.00 mm on the inside. The depth measures 9.00 mm.



The inner diameter of #3DBenchy's hawsepipe measures 4.00 mm. The depth of the flange against the hull is 0.30 mm.



The rectangular front window measures 10.50 x 9.50 mm. Its parallel inner surfaces are horizontally cut into the bridge.



The inner diameter of the cylindrical stern window measures 9.00 mm. Its outer diameter measures 12.00 mm. The flange's depth is 0.30 mm.



#3DBenchy's high-cain spoon bow has a 40° overhang angle to the horizontal plane.

The roof of the bridge slopes at a 5.5° angle to the horizontal plane.

The sign and small letters at the stern are extruded at 0.10 mm.

Lithophane

- ***French - is an etched or molded artwork in very thin translucent porcelain that can only be seen clearly when backlit with a light source ~ 1820's***
- ***It is a design or scene engraved that appears in gray tones***

https://en.wikipedia.org/wiki/Lithophane

Lithophane

https://en.wikipedia.org/wiki/Lithophane


Cura - 15.04.6
File Tools Machine Expert Help
Basic Advanced Plugins Start/End-GCode
Quality
Layer height (mm) 0.1
Shell thickness (mm) .8
Enable retraction
Fill
Bottom/Top thickness (mm) 0.8
Fill Density (%) 100
Speed and Temperature
Print speed (mm/s) 40
Printing temperature (C) 210
Bed temperature (C) 70
Support
Support type Touching buildplate
Platform adhesion type None
Filament
Diameter (mm) 1.75
Flow (%) 100.0
Machine
Nozzle size (mm) 0.4
3 hours 59 minutes
3.87 meter 12 gram
0.27

Parametric Designs

THE PARAMETRIC ULTIMATE BOX MAKER

OpenSCAD Parametric Box

- ***Parametric (.scad) files***
- ***Parameters can be changed in one place***
- ***All code related to the parameters change at once***
- ***In this case the width, height and length is described once***



Editor

```
25
26
27  ////////// - Paramètres de
        la boite - Box
        parameters - ////////////
28
29  /* [Box dimensions] */
30  // - Longueur - Length
31    Length          = 110;
32  // - Largeur - Width
33    Width           = 90;

34  // - Hauteur - Height
35    Height          = 30;
36  // - Epaisseur - Wall
        thickness
37    Thick           = 2;//[2:5]
38
39  /* [Box options] */
40  // Pieds PCB - PCB feet (x4)
41    PCBFeet         = 0;//
        [0:No, 1:Yes]
42  // - Decorations to
        ventilation holes
43    Vent            = 0;//
        [0:No, 1:Yes]
44  // - Decoration-Holes width
        (in mm)
45    Vent_width      = 1.5;
46  // - Text you want
47    txt             = "HeartyGFX"
        ;
48  // - Font size
49    TxtSize         = 3;

50  // - Font
51    Police          ="Arial
        Black";
```



Console

```
Geometries in cache: 41
Geometry cache size in bytes: 307032
CGAL Polyhedrons in cache: 0
CGAL cache size in bytes: 0
Compiling design (CSG Products normalization)...
Normalized CSG tree has 109 elements
```

Editor

```
25
26
27  ////////// - Paramètres de
        la boite - Box
        parameters - ////////////
28
29  /* [Box dimensions] */
30  // - Longueur - Length
31    Length          = 60;
32  // - Largeur - Width
33    Width           = 90;
34  // - Hauteur - Height
35    Height          = 30;
36  // - Epaisseur - Wall
        thickness
37    Thick           = 2;//[2:5]
38
39  /* [Box options] */
40  // Pieds PCB - PCB feet (x4)
41    PCBFeet         = 0;//
        [0:No, 1:Yes]
42  // - Decorations to
        ventilation holes
43    Vent            = 0;//
        [0:No, 1:Yes]
44  // - Decoration-Holes width
        (in mm)
45    Vent_width      = 1.5;
46  // - Text you want
47    txt             = "HeartyGFX"
        ;
48  // - Font size
49    TxtSize         = 3;
50  // - Font
51    Police          ="Arial
```



Console

```
Geometries in cache: 59
Geometry cache size in bytes: 419064
CGAL Polyhedrons in cache: 0
CGAL cache size in bytes: 0
Compiling design (CSG Products normalization)...
```

NBEMS Interface

5 January 2018










1725
2.2MF 2.2MF


KC7O
NBEMS


KC7O
NBEMS

Protector for Umbrella Pole in a glass table

Protector.scad* - OpenSCAD

File Edit Design View Help

Editor

```
1  //Glass Table Umbrella Protect
       Insert - Parametric
2  //A. Wolff - 29 November 2016
3  $fn=64;
4  //Hole In Glass
5      h = 49;
6  //Tube Diameter
7      t = 38.5;
8  //Outside Diameter Of Plug
9      d = 60;
10 //Height above table
11     p=5;
12 //Plug height through Glass
13     g=15;
14 difference(){
15 union(){
16 //Lip
17     translate([0,0,-.4])
18     cylinder(p,.4*d,.5*d);
19 //Plug
20     cylinder(g,.5*h,.5*h);
21 }
22 //Hole
23     translate([0,0,-.4])
24     cylinder(30,.5*t,.5*t);
25 }
```



Console

```
Simple:      yes
Vertices:    760
Halfedges:   2416
Edges:       1208
Halffacets:  904
Facets:      452
Volumes:     2
Rendering finished.
```

Viewport: translate = [13.85 -16.80 3.99], rotate = [236.30 0.00 305.90], distance = 140.00

Protector.scad* - OpenSCAD

File Edit Design View Help

Editor

```
1  //Glass Table Umbrella Protect
       Insert - Parametric
2  //A. Wolff - 29 November 2016
3  $fn=64;
4  //Hole In Glass
5      h = 49;
6  //Tube Diameter
7      t = 38.5;
8  //Outside Diameter Of Plug
9      d = 60;
10 //Height above table
11     p=5;
12 //Plug height through Glass
13     g=15;
14 difference(){
15 union(){
16 //Lip
17     translate([0,0,-.4])
18     cylinder(p,.4*d,.5*d);
19 //Plug
20     cylinder(g,.5*h,.5*h);
21 }
22 //Hole
23     translate([0,0,-.4])
24     cylinder(30,.5*t,.5*t);
25 }
```



Console

```
Simple:     yes
Vertices:   760
Halfedges:  2416
Edges:      1208
Halffacets: 904
Facets:     452
Volumes:    2
Rendering finished.
```

Viewport: translate = [13.85 -16.80 3.99], rotate = [236.30 0.00 305.90], distance = 140.00

Protector.scad* - OpenSCAD

File Edit Design View Help

Editor

```
1  //Glass Table Umbrella Protect
       Insert - Parametric
2  //A. Wolff - 29 November 2016
3  $fn=64;
4  //Hole In Glass
5      h = 49;
6  //Tube Diameter
7      t = 38.5;
8  //Outside Diameter Of Plug
9      d = 60;
10 //Height above table
11     p=5;
12 //Plug height through Glass
13     g=15;
14 difference(){
15 union(){
16 //Lip
17     translate([0,0,-.4])
18     cylinder(p,.4*d,.5*d);
19 //Plug
20     cylinder(g,.5*h,.5*h);
21 }
22 //Hole
23     translate([0,0,-.4])
24     cylinder(30,.5*t,.5*t);
25 }
```



Console

```
Simple:     yes
Vertices:   760
Halfedges:  2416
Edges:      1208
Halffacets: 904
Facets:     452
Volumes:    2
Rendering finished.
```

Viewport: translate = [13.85 -16.80 3.99], rotate = [236.30 0.00 305.90], distance = 140.00



Try 3D Printing


Ext0
Bed




You don’t have to be an Einstein!